

ALLISON HYBRID

DIAGNOSTICS – USING THE TROUBLESHOOTING MANUAL




Instructor Led Training

Using The Troubleshooting Manual

Introduction

- Allison Hybrid H 40/50 EP System Troubleshooting Manual:
 - Publication number TS3715EN.
- Shares a similar design and layout to other Allison troubleshooting manuals.



1 of 7



ALLISON HYBRID

DIAGNOSTICS – USING THE TROUBLESHOOTING MANUAL




Instructor
Led
Training

Using The Troubleshooting Manual

Troubleshooting Manual Sections

- **Electrical Safety section:**
 - *Procedures for safely working with the voltages present in the system.*
- **General Description section:**
 - *Overviews Electronic Control system components and operation.*
- **Definitions and Abbreviations:**
 - *Provides descriptions of key terms and acronyms.*
- **Basic Knowledge section:**
 - *Describes basic information technicians need for successful troubleshooting.*



View PDF View PDF View PDF View PDF

2 of 7



ALLISON HYBRID

RESOURCES: Electrical Safety



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

ELECTRICAL SAFETY

WARNING!

The Allison Electric Drive EP 40/50 System™ uses potentially hazardous electrical energy. All EP 40/50 System™ components are identified with warning labels or symbols (see Figure 1, Figure 2, and Figure 3). DO NOT attempt to service components containing potentially hazardous electrical energy if you are not trained to do so.

All persons working with potentially hazardous electric energy should familiarize themselves with safe electrical work practices. Paragraph f in Electrical Safety section contains references to publicly available documentation that can assist a technician in developing the safe electrical work practices required to service the EP 40/50 System™ electrical system.

EP 40/50 System™ Normal Operating Conditions

ESS Voltage Range: 432–780VDC
DPIM Voltage Range: –350 to +350A



V10323.00.00

Figure 1. DPIM Warning Label



V10322.00.00

Figure 2. ESS Warning Label



RESOURCES: General Description



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

SECTION 1—GENERAL DESCRIPTION

1-1. EP 40/50 SYSTEM™

The Allison EP 40/50 System™ is a fully automatic, electronically-controlled, fuel efficient and low emission means to provide propulsion for transit buses and medium- or heavy-duty trucks. The EP 40/50 System™ is described as a two-mode compound split parallel hybrid architecture. The following terms define the architecture:

- Two-mode—a low (Mode 1) and a high speed (Mode 2) range.
- Compound Split—engine torque and electric motor torque are continuously blended through an input split (Motor A) and output split (Motor B).
- Parallel—two parallel torque paths available for transmitting engine and motor/generator torque through the transmission as output torque.
- Hybrid—combines an internal combustion (IC) engine with electrical machines to provide propulsion.

The EP 40/50 System™ provides “engine buffering and decoupling” to limit the rate of engine rpm change and to keep the engine operating at its most fuel efficient, low emission tuned, torque-speed points.

An Allison EP 40/50 System™ consists of the following four main components:

- E^V Drive™—serves as the vehicle transmission.
- Transmission Control Module (TCM)/Vehicle Control Module (VCM)—a pair of master microprocessor-based controllers that operate together to process data and request action for operation of the EP 40/50 System™ and other vehicle features. The TCM/VCM communicate with other microprocessor-based controllers on a Controller Area Network (CAN) inside and outside the EP 40/50 System™ using an SAE J1939 compliant datalink.
- Dual Power Inverter Module (DPIM)—provides inverter power electronics for E^V Drive™ propulsion and for charging the Energy Storage System (ESS).
- Energy Storage System (ESS)—uses advanced Nickel Metal Hydride (NiMH) batteries as the electrical power source for the EP 40/50 System™.

1-2. E^V DRIVE™

The E^V Drive™ is designed to combine (torque blend) electrical machine torque with engine torque while driving in a forward direction. The E^V Drive™ does not have fixed gear ratios as does a typical automatic transmission. The gear ratios, speed ratios, and torque ratios through the E^V Drive™ are continuously variable until maximum ratings are reached. The E^V Drive™ has three planetary gear sets, two clutches, and two electrical machines (motor/generators).



RESOURCES: Definitions and Abbreviations



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

SECTION 2—DEFINITIONS AND ABBREVIATIONS

2-1. DASH INDICATOR LIGHTS

The electronic control system is programmed to inform the operator of a problem with the EP 40/50 System™ and automatically take action to protect the operator, vehicle, and transmission. To do this, the VCM turns on a **DASH INDICATOR LIGHT** on the instrument panel, which notifies the operator that a Diagnostic Trouble Code (DTC) has been stored.

WAIT TO START—The **WAIT TO START** light is located on the dash panel. This indicator notifies the operator that the vehicle system is not ready to start. The light is extinguished when the vehicle systems are ready for start-up. If the indicator remains illuminated, check the PBSS for diagnostic codes related to the EP 40/50 System™. Continued illumination of this indicator can also indicate vehicle system inhibits.

SYSTEM OVERTEMP—The **SYSTEM OVERTEMP** warning light is located on the dash panel and alerts the operator when any of the EP 40/50 System™ components has reached a thermal limit. Overtemp faults result in reduced performance or a disabled propulsion condition. Check the PBSS for specific diagnostic trouble codes (DTC).

CHECK SYSTEM—The **CHECK SYSTEM** warning light is located on the dash panel and alerts the operator that an EP 40/50 System™ fault has occurred. Vehicle propulsion will not be disabled when **CHECK SYSTEM** is illuminated. Immediately return the vehicle for service. If a fault occurs a Diagnostic Trouble Code for that fault is logged into diagnostic system memory. Check the PBSS for specific DTCs.

STOP SYSTEM—The **STOP SYSTEM** warning light is located on the dash panel and alerts the operator that a EP 40/50 System™ fault has occurred. Faults of this nature automatically disable the propulsion system. The driver will have approximately 30 seconds to move the vehicle to a safe location before the EP 40/50 System™ is disabled. During this time, the **STOP SYSTEM** light will flash. Stop the vehicle immediately and remove it from service. If a fault occurs, a DTC for that fault is logged into diagnostic system memory. Check the PBSS for specific DTCs.

2-2. ALLISON DOC™ FOR PC (AED)

The Allison DOC™ For PC (AED)—Service Tool is the preferred service tool for the EP 40/50 System™. The Allison DOC™ For PC (AED)—Service Tool connects to the J1939 CAN at the diagnostic connector inside the vehicle. The Allison DOC™ For PC (AED)—Service Tool can display logged codes including those related to the ESS. The service tool also has the capability of recording operating conditions for later playback or to display system operating conditions in real-time. Refer to the Allison DOC™ For PC (AED)—Service Tool User Guide GN3727EN for full capabilities of the service tool.




Figure 2-1. Allison DOC™ For PC (AED)



RESOURCES: Basic Knowledge



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

SECTION 3—BASIC KNOWLEDGE

3-1. BASIC KNOWLEDGE REQUIRED

To service EP 40/50 System™ Electronic Controls, the technician must understand basic electrical concepts. Technicians need to know how to use a volt/ohmmeter (VOM) to make resistance and continuity checks. Most troubleshooting checks consist of checking resistance and continuity, and checking for shorts between wires and to ground. The technician should be able to use jumper wires and breakout harnesses and connectors. Technicians unsure of making the required checks should ask questions of experienced personnel or find instruction.

The technician should also have the mechanical aptitude required to connect pressure gauges or transducers to identified pressure ports used in the troubleshooting process. Pressure tap locations and pressure values are shown in Appendix B.

Input power, ground, neutral start circuitry, etc., can cause problems with electronic controls or vehicle functioning and may not generate a DTC. A working knowledge of EP 40/50 System™ Electronic Controls vehicle installation is necessary in troubleshooting installation-related problems.

Refer to Section 7 for information concerning performance complaints (non-DTC) troubleshooting. A complete wiring schematic is shown in Appendix H. Refer to the Tech Data Book for information concerning electronic controls installation and the Installation Checklist. Reliable transmission operation and performance depend upon a correctly installed transmission. Review the Installation Checklist in the EP 40/50 System™ Tech Data Book for proper installation.

NOTE: *Allison Transmission is providing for service of wiring harnesses and wiring harness components as follows:*

- *Repair parts for the internal wiring harness will be available through the Allison Transmission Parts Distribution Center (PDC). Use the P/N from your appropriate parts catalog or from Appendix E in this manual. Allison Transmission is responsible for warranty on these parts.*
- *Repair parts for the external harnesses and external harness components must be obtained through the vehicle OEM. The OEM is responsible for warranty on these parts.*

3-2. USING THE TROUBLESHOOTING MANUAL

Use this manual as an aid to troubleshooting the EP 40/50 System™ Electronic Controls. Every possible problem and its solution cannot be encompassed by any manual. However, this manual does provide a starting point from which most problems can be resolved.

Once a problem solution is discovered in the manual do not look further for other solutions. It is necessary to determine why a problem occurred. The root cause of a problem as well as the symptom must be corrected to ensure trouble free operation. For example, taping a wire that has been rubbing on a frame rail will not correct the problem unless the rubbing contact is eliminated.

NOTE: *Information concerning specific items is contained in the appendices located in the back of this manual. The appendices are referred to throughout the manual.*

3-3. IMPORTANT INFORMATION IN THE TROUBLESHOOTING PROCESS

Before beginning the troubleshooting process, read and understand the following:

- Allison recommended wire numbers (i.e. 212) are a combination of the first digit indicating the TCM connector number (i.e. J2) and the last two digits indicating the pin-out information (i.e. 12).
- Shut off the engine and ignition before any harness connectors are disconnected or connected.
- Remember to do the following when checking for shorts and opens:
 - Minimize movement of wiring harnesses when looking for shorts. Shorts involve wire-to-wire or wire-to-ground contacts and moving the harnesses may eliminate the problem.
 - Wiggle connectors, harnesses, and splices when looking for opens. This simulates vehicle movements which occur during actual operation.
- When disconnecting a harness connector, be sure that pulling force is applied to the connector itself and **not the wires** extending from the connector.



ALLISON HYBRID

DIAGNOSTICS – USING THE TROUBLESHOOTING MANUAL




Instructor Led Training

Using The Troubleshooting Manual

Troubleshooting Manual Sections (cont'd)

- **Wire Check Procedures:**
 - *Describes the procedures used to check harness wires for opens and shorts.*
- **Diagnostic Codes section:**
 - *Provides detailed step-by-step procedures for troubleshooting DTCs.*
- **Input and Output Functions section:**
 - *Provides an overview of how Inputs and Outputs interact with the Electronic Controls.*
- **General Troubleshooting section:**
 - *Describes diagnostic steps to take when DTCs are not logged in the TCM/VCM memory.*



View PDF View PDF View PDF View PDF

3 of 7



ALLISON HYBRID

RESOURCES: Wire Check Procedures



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

SECTION 4—WIRE CHECK PROCEDURES

4-1. CHECKING OPENS, SHORTS BETWEEN WIRES, AND SHORTS-TO-GROUND (Use Digital Volt/Ohmmeter J 34520-A and Jumper Wire Set J 39197)

NOTE: Please refer to Paragraph 3-4 to begin the troubleshooting process.

1. Make sure all connectors are tightly connected and re-check the circuit.
2. Disconnect and inspect all connectors.
3. Thoroughly clean corroded or dirty terminals. If dirty or corroded terminals are the probable cause of the problems, reconnect the clean connectors and operate the vehicle normally. If the problem recurs, proceed with Step (4).

CAUTION:

The cleaning solvent must not be chlorine based, contain petroleum distillates, or conduct electricity. The cleaning solvent should evaporate quickly to prevent the possibility of condensation within the connectors. Always blow or shake any excess cleaner from the connector before assembling it to its mating connector or hardware. Cleaner trapped in the connector can affect the connector seal. (Refer to SIL 17-TR-94 for detailed information on the recommended cleaners.)

4. Review the wire numbering system described in Paragraph 3-3.
5. If all connectors are clean and properly seated, determine which wires in the chassis harness are indicated by the DTC.
 - a. Check continuity of wires 422 and 423 by performing the following (Figure 4-1):
 - (1) Disconnect the red (J2) connector from the TCM and disconnect the harness from the transmission main connector. At one end of the harness, using jumper wire kit J 39197 and connector probes in J 39775-CP, connect wire 422 and 423 to each other, being careful not to distort the terminals. Jumping the wires together creates a circuit between wires 422 and 423.




Figure 4-1. Checking Continuity (External Harness)



RESOURCES: Diagnostic Trouble Codes (DTCs)

NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

E^P 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

SECTION 5—DIAGNOSTIC TROUBLE CODES (DTC)

5-1. DTC MEMORY

Diagnostic Trouble Codes (DTCs) are logged into the TCM, listing the most recent DTC first and logging up to nine DTCs. The shift selector will display DTCs in main code/subcode format in the order that they occurred, with the most recent on the shift selector first, and whether the DTC is active (the **MODE** indicator is illuminated for active DTCs). Allison DOC™ For PC (AED) will display the following DTC information:

- Main code
- Subcode
- Whether the DTC is active
- Whether the **STOP SYSTEM** indicator is lit
- Whether the **CHECK SYSTEM** indicator is lit
- Whether the **SYSTEM OVER-TEMP** indicator is lit
- Whether there is a failure record associated with that DTC
- How many times the DTC has occurred
- A description of the DTC

5-2. FAILURE RECORDS

Failure records contain a snapshot of EP 40/50 System™ information that is stored in the TCM when some DTCs are logged. A limit of five failure records can be stored. When an additional DTC with a failure record is logged, the new failure record replaces the oldest record in the TCM memory. The failure records can only be viewed with Allison DOC™ For PC (AED). The information included in a failure record is listed below:

Table 5-1. Failure Record Data

Data Description
PBSS Range Selected
Range State
Transmission Fluid Level
TCM Ignition Voltage
Sump Fluid Temperature
Accelerator Pedal Percent
Brake Percent
Engine Speed
C1 Blocking Solenoid Command
C1 Solenoid Current
C1 Pressure Switch
C2 Blocking Solenoid Command
C2 Solenoid Current
C2 Pressure Switch
Main Pressure Command
Output Speed
Output Torque
Energy Storage Pack SOC (State of Charge)
Inverter A Motor Speed



RESOURCES: Input/Output Functions




NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX L—INPUT/OUTPUT FUNCTIONS

L-1. AUX FUNCTION RANGE INHIBIT



WARNING!

If this function is enabled in the calibration, the function **MUST** be integrated into the vehicle wiring. If the function is available in the calibration but will not be used in the vehicle, it **MUST** be disabled in the calibration.

DESCRIPTION: When this function is used and an auxiliary vehicle function is active, a neutral-to-range shift is inhibited. It will continue to be inhibited until the input signal from the auxiliary vehicle function is turned off.

NOTE: *This function is active when the input is off (switch open) and is deactivated when the input is turned on (switch closed).*

USES: This function prevents inadvertent range selection when auxiliary equipment, e.g., wheelchair lift, is operating. It may also be used to prevent neutral-to-range shifts unless the brake pedal is depressed.

VARIABLES TO SPECIFY: None

VOCATIONS: Various, not for emergency equipment. Typical uses: transit bus (wheelchair lift), utility truck (outriggers out), and motorhome (door ajar).



RESOURCES: General Troubleshooting

SECTION 7—GENERAL TROUBLESHOOTING OF PERFORMANCE

IMPORTANT:

Make the following general checks before beginning specific troubleshooting or removing the system components.

- Are there active DTCs?
- Is the shift selector lever in **N** (Neutral) to allow starting the engine?
- Is the 12/24V battery properly connected and charged?
- Is isolated battery properly connected (if used)?
- Is the fluid level correct?
- Is voltage to the TCM/VCM correct?
- Is the engine properly tuned?
- Is fuel flow to the engine correct?
- Are wheel chocks in place?
- Is air flow to the cooler and radiator unrestricted?
- Is the driveline properly connected?
- Are there signs of fluid leakage under the vehicle? What is the origination point?
- Are hydraulic connections correctly made and not leaking?
- Has the vehicle acceleration rate been changed?
- Are electrical connections correct?
- Are there any other obvious vehicle or hybrid system problems?

After making these general checks use the various sections of this manual to isolate the listed problems. The following charts address specific vehicle complaints. Some complaints involve DTCs, so all troubleshooting checks should involve first checking the system for DTCs.

Performance Complaints

- A. Sluggish Vehicle Performance**
Use Allison DOC™ For PC (AED) to compare the commanded versus actual engine torque—if the two values are different, check the engine for trouble codes. Check the Battery Charge Limit ID for any conditions that may limit ESS output.
- B. PBSS displays a Cat-Eye**
Check for loss of wake-up signal to PBSS and check the SDL wiring.
- C. STOP SYSTEM light on with no codes and blank fields in DOC where TCM info should be**
Possible CAN problem or power/wake-up problem with TCM. Reference the CAN Troubleshooting in Appendix of this manual.
- D. CHECK SYSTEM lamp on without a fault code**
Likely caused by a system override switch failing to the ON position (triggered by an open circuit or unconnected switch).
- E. Rough shifts**
With engine running, cycle the vehicle from **F** to **N**. The shift to Neutral cycles the shift solenoids (fully opening the armature), allowing for any possible debris to pass.
- F. High engine speed at idle**
Part of normal vehicle operation when the ESS SOC is low.



ALLISON HYBRID

DIAGNOSTICS – USING THE TROUBLESHOOTING MANUAL



Instructor Led Training


Using The Troubleshooting Manual

Troubleshooting Manual Appendices

- **Diagnosing Intermittent DTCs:**
 - Information on identifying, locating and resolving issues that cause intermittent DTCs to be logged.
- **Main Pressure Check Procedure:**
 - Helps technicians determine if a transmission malfunction is due to a mechanical or electrical problem.
- **Solenoid and Clutch Tables:**
 - Indicates solenoid states and clutch application status during shifts and when ranges have been attained.
- **Wire and Connector Tables:**
 - Provides terminal and wire designations for Electronic Control connectors and harnesses.

Table B-1. Pressure Schedule (kPa)

Engine Input Speed (rpm)	Range	Applied Clutch	Full Boost Main Pressure (kPa)	Low Main Pressure (kPa)	Control Main Pressure (kPa)	C1 Pressure (kPa)	C2 Pressure (kPa)	Little Pressure (kPa)
755-795	N	-	2000-2400	770-1070	495-605	8-20	8-20	30-70
755-795	F1	C1	2000-2400	770-1070	495-605	Main +0/-70	8-20	30-70
755-795	F2	C2	2000-2400	770-1070	495-605	8-20	Main +0/-70	30-70
755-795	R	C1	-	-	-	-	-	-



View PDF View PDF View PDF View PDF

4 of 7



RESOURCES: Diagnosing Intermittent DTCs

NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

E^P 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX A—DIAGNOSING INTERMITTENT DTCs

Intermittent Diagnostic Trouble Codes (DTC) are a result of faults that are detected, logged, and then become inactive, only to recur later. If, when troubleshooting, a DTC is cleared in anticipation of it recurring and it does not, check the items in the following list for the fault's source.

A. Circuit Inspection

1. Intermittent power/ground problems — can cause voltage problems during TCM diagnostic checks which can set various DTCs depending upon where the TCM was in the diagnostic process.
2. Damaged terminals.
3. Dirty or corroded terminals.
4. Terminals not fully seated in the connector. Check indicated wires by uncoupling connector and gently pulling on the wire at the rear of the connector and checking for excessive terminal movement.
5. Connectors not fully mated. Check for missing or damaged locktabs.
6. Screws or other sharp pointed objects pushed into or through one of the harnesses.
7. Harnesses which have rubbed through and may be allowing intermittent electrical contact between two wires or between wires and vehicle frame members.
8. Broken wires within the braiding and insulation.

B. Finding an Intermittent Fault Condition

To find a fault, like one of those listed, examine all connectors and the external wiring harnesses. Harness routing may make it difficult to see or feel the complete harness. However, it is important to thoroughly check each harness for chafed or damaged areas. Road vibrations and bumps can damage a poorly installed harness by moving it against sharp edges and cause some of the faults. If a visual inspection does not identify a cause, move and wiggle the harness by hand until the fault is duplicated.

The next most probable cause of an intermittent DTC is an electronic part exposed to excessive vibration, heat, or moisture. Examples of this are:

1. Exposed harness wires subjected to moisture.
2. A defective connector seal allows moisture to enter the connector or part.
3. An electronic part (TCM, VCM, solenoid, or throttle sensor) affected by vibration, heat, or moisture may cause abnormal electrical conditions within the part.

When troubleshooting Item 3, eliminate all other possible causes before replacing any parts.

Another cause of intermittent DTCs is an abnormal environment. The abnormal environment will usually include excessive heat, moisture, or voltage. For example, a TCM that receives excessive voltage will generate a diagnostic code as it senses high voltage in a circuit. The DTC may not be repeated consistently because different circuits may have this condition on each check. The last step in finding an intermittent DTC is to observe if the DTC is set during sudden changes in the operating environment.

Troubleshooting an intermittent DTC requires looking for common conditions that are present whenever the DTC is diagnosed. Use the failure record information from the Allison DOC™ For PC (AED) tool to identify the conditions when the DTC was set.



RESOURCES: Main Pressure Check

APPENDIX B—MAIN PRESSURE CHECK PROCEDURE

Checking main pressures helps to determine if a transmission malfunction is due to a mechanical or an electrical problem. Properly making these pressure checks requires transmission and vehicle (or test stand) preparation, recording of data, and comparing recorded data against specifications provided.

WARNING! Observe safety precautions during hydraulic pressure check procedures. All personnel must stand clear of the vehicle. Take precautions against movement of the vehicle. Be sure that gauges (vacuum, pressure, tachometer) have extended lines so that they can be read from inside the vehicle.

1. All transmission fluid level and pressure checks must be made at normal operating temperatures. Check transmission fluid level.
2. Connect a 0–2070 kPa (0–300 psi) oil pressure gauge at the main pressure tap. Use the Allison DOC™ For PC to check engine rpm. See Pressure Schedule Tables for main pressure levels. Record your measurement.
3. With brakes applied, check main pressure with the engine running at 2100 rpm and 800 rpm.
4. Use the Allison DOC™ For PC to command full main boost pressure, repeat previous step and record your measurement.

Table B-1. Pressure Schedule (kPa)

Engine Input Speed (rpm)	Range	Applied Clutch	Full Boost Main Pressure (kPa)	Low Main Pressure (kPa)	Control Main Pressure (kPa)	C1 Pressure (kPa)	C2 Pressure (kPa)	Lube Pressure (kPa)
755–795	N	–	2030–2400	770–1070	495–605	8–20	8–20	30–70
755–795	F1	C1	2030–2400	770–1070	495–605	Main +0/-70	8–20	30–70
755–795	F2	C2	2030–2400	770–1070	495–605	8–20	Main +0/-70	30–70
755–795	R	C1	2030–2400	770–1070	495–605	Main +0/-70	Main +0/-70	30–70

Table B-2. Pressure Schedule (psi)

Engine Input Speed (rpm)	Range	Applied Clutch	Full Boost Main Pressure (psi)	Low Main Pressure (psi)	Control Main Pressure (psi)	C1 Pressure (psi)	C2 Pressure (psi)	Lube Pressure (psi)
755–795	N	–	294–348	112–155	72–88	1–3	1–3	4–10
755–795	F1	C1	294–348	112–155	72–88	Main +0/-10	1–3	4–10
755–795	F2	C2	294–348	112–155	72–88	1–3	Main +0/-10	4–10
755–795	R	C1	294–348	112–155	72–88	Main +0/-10	Main +0/-10	4–10



ALLISON HYBRID

RESOURCES: Solenoid and Clutch Tables

APPENDIX C—SOLENOID AND CLUTCH TABLES

Normal operation of the transmission requires application of a clutch to attain forward or reverse range. A unique combination of solenoid and shift valve actuation produces clutch application in a given range. Table C-1 lists the transmission range shifts, the clutch that is applied in each range, and the electrical state (On/Off) of each solenoid for each range.

Table C-1. Solenoid Pressurized Clutch Table

Range	Solenoid					C1	C2
	C1	C2	C1 Block	C2 Block	Boost		
F1	X	–	X	–	#	X	–
F2	–	X	–	X	#	–	X
N	–	–	–	–	#	–	–
R	X	–	X	–	#	X	–

X = Solenoid energized or clutch applied.

= Apply boost solenoid to modulated main pressure (0.00 amps = full boost pressure, 0.77 amps = low main pressure)



ALLISON HYBRID

RESOURCES: Wire/Connector Tables



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

WIRE/CONNECTOR TABLES




Figure D-1. TCM Connector J2

TCM CONNECTOR J2 (RED)

Terminal No.	Color	Wire No.	Description	Termination Point(s)
1	Blue	158	C1 Pressure Switch	Trans-C
2				
3				
4				
5	Red	160	Fast Idle 2	Vehicle System
6	Green	250	Remote Shutdown Request (application specified mode #4)	Vehicle System
7	Blue	251	Accelerator Interlock	Vehicle System
8	Tan	161	C2 Pressure Switch	Trans-E
9				
10	White	163	Sump Oil Temp	Trans-L
11				
12				
13	White	165	Transmission Output Speed 2 HI	NO2-A
14	White	166	Transmission Output Speed 2 LO	NO2-B
15	White	167	Transmission Output Speed 1 HI	NO1-A
16	White	168	Transmission Output Speed 1 LO	NO1-B
17				
18				
19				
20	Black	170	Analog Ground	Trans-D, F, M, P
21	Pink	171	Trans ID	Trans-G
22	Blue	172	C1 Solenoid Command HI	Trans-S
23	White	173	C1 Solenoid Enable LO	Trans-T
24	Blue	174	C2 Solenoid Command HI	Trans-U
25	Green	175	C2 Solenoid Enable LO	Trans-V
26	Pink	176	C1 Block Solenoid	Trans-B
27	Red	177	C2 Block Solenoid	Trans-R
28	White	178	Inverter Wake-up, A & B	Vehicle System



ALLISON HYBRID

DIAGNOSTICS – USING THE TROUBLESHOOTING MANUAL




Instructor
Led
Training

Using The Troubleshooting Manual

Troubleshooting Manual Appendices (cont'd)

- **Connector Repair Information:**
 - Lists the special tools and part numbers required when repairing Electronic Control connectors.
- **Welding on Vehicle:**
 - Includes warnings and recommended procedures to follow when welding on the vehicle.
- **Hydraulic Schematics:**
 - Range-by-range hydraulic system flows.
- **Wiring Schematics:**
 - Detailed electrical schematics including component terminal, wire and switching status information.



View PDF View PDF View PDF View PDF

5 of 7



ALLISON HYBRID

RESOURCES: Connector Repair Information



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

E^P 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

CONNECTOR REPAIR INFORMATION

List Of Special Tools Required To Service Wiring Harnesses

Tool Number	Tool Type	Paragraph Reference
23046604	Splice, Sealed (14–16 AWG)	E–7
23046605	Splice, Sealed (18–22 AWG)	E–7
J 25070	Heat Gun	E–7
J 34182	Crimper 1	E–1, E–5, E–6
J 34513	Remover 1	E–1, E–5
J 35123	Crimper (Alternate)	E–2
J 35606	Crimper (Alternate)	E–4
J 35615	Wire Stripper 1	E–2, E–7
J 35689-A	Remover	E–2
J 38125-10	Remover	E–4
J 38125-6	Crimper	E–4
J 38125-7	Crimper	E–2
J 38125-8	Crimper	E–7
J 38582-3	Remover	E–1, E–5
J 38852	Crimper (Alternate)	E–4
J 41194	Extractor/Insertter	E–1, E–5
J 42215	Crimper	E–1



Appendix F—WELDING ON VEHICLE

F-1. WELDING ON VEHICLE

When frame or other welding is required on the vehicle, take the following precautions to protect the electronic control components:

1. Disconnect the wiring harness connectors at the TCM, VCM, DPIM, and ESS.
2. Disconnect the positive and negative battery connections, and any electronic control ground wires connected to the frame or chassis.
3. Cover electronic control components and wiring to protect them from hot sparks, etc.
4. Do not connect welding cables to electronic control components.

CAUTION:

When welding on the vehicle:


- DO NOT WELD on the vehicle without disconnecting all control system harness connectors from the TCM, VCM, DPIM, and ESS.
- DO NOT WELD on any system components including the DPIM and ESS.
- DO NOT CONNECT welding cables to any system components.



ALLISON HYBRID

RESOURCES: Hydraulic Schematics

APPENDIX G—HYDRAULIC SCHEMATICS



Foldout G-3. Neutral Range

ALLISON HYBRID

RESOURCES: Wiring Schematics

APPENDIX H—EP 40/50 SYSTEM™ WIRING SCHEMATIC




Figure H-1. Allison Electric Drive™ Wiring Schematic—TCM

PN	WIRE NO.	RECOMMENDED COLOR	CABLE™	DESCRIPTION
FT1	11820151-1	RED	C	12V BATTERY
FT2	11820151-2	RED	C	12V BATTERY
FT3	11820151-3	RED	D	IGNITION
FT4	11820151-4	RED	E	12V BATTERY
FT5	11820151-5	RED	F	12V BATTERY
FT6	11820151-6	RED	G	12V BATTERY
FT7	11820151-7	RED	H	12V BATTERY
FT8	11820151-8	RED	I	12V BATTERY
FT9	11820151-9	RED	J	12V BATTERY
FT10	11820151-10	RED	K	12V BATTERY
FT11	11820151-11	RED	L	12V BATTERY
FT12	11820151-12	RED	M	12V BATTERY
FT13	11820151-13	RED	N	12V BATTERY
FT14	11820151-14	RED	O	12V BATTERY
FT15	11820151-15	RED	P	12V BATTERY
FT16	11820151-16	RED	Q	12V BATTERY
FT17	11820151-17	RED	R	12V BATTERY
FT18	11820151-18	RED	S	12V BATTERY
FT19	11820151-19	RED	T	12V BATTERY
FT20	11820151-20	RED	U	12V BATTERY
FT21	11820151-21	RED	V	12V BATTERY
FT22	11820151-22	RED	W	12V BATTERY
FT23	11820151-23	RED	X	12V BATTERY
FT24	11820151-24	RED	Y	12V BATTERY
FT25	11820151-25	RED	Z	12V BATTERY
FT26	11820151-26	RED	AA	12V BATTERY
FT27	11820151-27	RED	AB	12V BATTERY
FT28	11820151-28	RED	AC	12V BATTERY
FT29	11820151-29	RED	AD	12V BATTERY
FT30	11820151-30	RED	AE	12V BATTERY
FT31	11820151-31	RED	AF	12V BATTERY
FT32	11820151-32	RED	AG	12V BATTERY
FT33	11820151-33	RED	AH	12V BATTERY
FT34	11820151-34	RED	AI	12V BATTERY
FT35	11820151-35	RED	AJ	12V BATTERY
FT36	11820151-36	RED	AK	12V BATTERY
FT37	11820151-37	RED	AL	12V BATTERY
FT38	11820151-38	RED	AM	12V BATTERY
FT39	11820151-39	RED	AN	12V BATTERY
FT40	11820151-40	RED	AO	12V BATTERY
FT41	11820151-41	RED	AP	12V BATTERY
FT42	11820151-42	RED	AQ	12V BATTERY
FT43	11820151-43	RED	AR	12V BATTERY
FT44	11820151-44	RED	AS	12V BATTERY
FT45	11820151-45	RED	AT	12V BATTERY
FT46	11820151-46	RED	AU	12V BATTERY
FT47	11820151-47	RED	AV	12V BATTERY
FT48	11820151-48	RED	AW	12V BATTERY
FT49	11820151-49	RED	AX	12V BATTERY
FT50	11820151-50	RED	AY	12V BATTERY
FT51	11820151-51	RED	AZ	12V BATTERY
FT52	11820151-52	RED	BA	12V BATTERY
FT53	11820151-53	RED	BB	12V BATTERY
FT54	11820151-54	RED	BC	12V BATTERY
FT55	11820151-55	RED	BD	12V BATTERY
FT56	11820151-56	RED	BE	12V BATTERY
FT57	11820151-57	RED	BF	12V BATTERY
FT58	11820151-58	RED	BG	12V BATTERY
FT59	11820151-59	RED	BH	12V BATTERY
FT60	11820151-60	RED	BI	12V BATTERY
FT61	11820151-61	RED	BJ	12V BATTERY
FT62	11820151-62	RED	BK	12V BATTERY
FT63	11820151-63	RED	BL	12V BATTERY
FT64	11820151-64	RED	BM	12V BATTERY
FT65	11820151-65	RED	BN	12V BATTERY
FT66	11820151-66	RED	BO	12V BATTERY
FT67	11820151-67	RED	BP	12V BATTERY
FT68	11820151-68	RED	BQ	12V BATTERY
FT69	11820151-69	RED	BR	12V BATTERY
FT70	11820151-70	RED	BS	12V BATTERY
FT71	11820151-71	RED	BT	12V BATTERY
FT72	11820151-72	RED	BU	12V BATTERY
FT73	11820151-73	RED	BV	12V BATTERY
FT74	11820151-74	RED	BW	12V BATTERY
FT75	11820151-75	RED	BX	12V BATTERY
FT76	11820151-76	RED	BY	12V BATTERY
FT77	11820151-77	RED	BZ	12V BATTERY
FT78	11820151-78	RED	CA	12V BATTERY
FT79	11820151-79	RED	CB	12V BATTERY
FT80	11820151-80	RED	CC	12V BATTERY
FT81	11820151-81	RED	CD	12V BATTERY
FT82	11820151-82	RED	CE	12V BATTERY
FT83	11820151-83	RED	CF	12V BATTERY
FT84	11820151-84	RED	CG	12V BATTERY
FT85	11820151-85	RED	CH	12V BATTERY
FT86	11820151-86	RED	CI	12V BATTERY
FT87	11820151-87	RED	CJ	12V BATTERY
FT88	11820151-88	RED	CK	12V BATTERY
FT89	11820151-89	RED	CL	12V BATTERY
FT90	11820151-90	RED	CM	12V BATTERY
FT91	11820151-91	RED	CN	12V BATTERY
FT92	11820151-92	RED	CO	12V BATTERY
FT93	11820151-93	RED	CP	12V BATTERY
FT94	11820151-94	RED	CQ	12V BATTERY
FT95	11820151-95	RED	CR	12V BATTERY
FT96	11820151-96	RED	CS	12V BATTERY
FT97	11820151-97	RED	CT	12V BATTERY
FT98	11820151-98	RED	CU	12V BATTERY
FT99	11820151-99	RED	CV	12V BATTERY
FT100	11820151-100	RED	CW	12V BATTERY

WIRE NUMBERS SHOWN IN SCHEMATIC ARE SUBJECT TO CHANGE WITHOUT NOTICE. REFER TO ALLISON TECHNICAL DOCUMENT NO. 18 FOR WIRE COLOR CHANGES.


WIRE CABLES ARE IDENTIFIED BY COLOR:

- A 0.5W 0.50mm
- B 0.5W 0.50mm
- C 0.5W 0.50mm
- D 0.5W 0.50mm
- E 0.5W 0.50mm
- F 0.5W 0.50mm
- G 0.5W 0.50mm
- H 0.5W 0.50mm
- I 0.5W 0.50mm
- J 0.5W 0.50mm
- K 0.5W 0.50mm
- L 0.5W 0.50mm
- M 0.5W 0.50mm
- N 0.5W 0.50mm
- O 0.5W 0.50mm
- P 0.5W 0.50mm
- Q 0.5W 0.50mm
- R 0.5W 0.50mm
- S 0.5W 0.50mm
- T 0.5W 0.50mm
- U 0.5W 0.50mm
- V 0.5W 0.50mm
- W 0.5W 0.50mm
- X 0.5W 0.50mm
- Y 0.5W 0.50mm
- Z 0.5W 0.50mm
- AA 0.5W 0.50mm
- AB 0.5W 0.50mm
- AC 0.5W 0.50mm
- AD 0.5W 0.50mm
- AE 0.5W 0.50mm
- AF 0.5W 0.50mm
- AG 0.5W 0.50mm
- AH 0.5W 0.50mm
- AI 0.5W 0.50mm
- AJ 0.5W 0.50mm
- AK 0.5W 0.50mm
- AL 0.5W 0.50mm
- AM 0.5W 0.50mm
- AN 0.5W 0.50mm
- AO 0.5W 0.50mm
- AP 0.5W 0.50mm
- AQ 0.5W 0.50mm
- AR 0.5W 0.50mm
- AS 0.5W 0.50mm
- AT 0.5W 0.50mm
- AU 0.5W 0.50mm
- AV 0.5W 0.50mm
- AW 0.5W 0.50mm
- AX 0.5W 0.50mm
- AY 0.5W 0.50mm
- AZ 0.5W 0.50mm
- BA 0.5W 0.50mm
- BB 0.5W 0.50mm
- BC 0.5W 0.50mm
- BD 0.5W 0.50mm
- BE 0.5W 0.50mm
- BF 0.5W 0.50mm
- BG 0.5W 0.50mm
- BH 0.5W 0.50mm
- BI 0.5W 0.50mm
- BJ 0.5W 0.50mm
- BK 0.5W 0.50mm
- BL 0.5W 0.50mm
- BM 0.5W 0.50mm
- BN 0.5W 0.50mm
- BO 0.5W 0.50mm
- BP 0.5W 0.50mm
- BQ 0.5W 0.50mm
- BR 0.5W 0.50mm
- BS 0.5W 0.50mm
- BT 0.5W 0.50mm
- BU 0.5W 0.50mm
- BV 0.5W 0.50mm
- BW 0.5W 0.50mm
- BX 0.5W 0.50mm
- BY 0.5W 0.50mm
- BZ 0.5W 0.50mm
- CA 0.5W 0.50mm
- CB 0.5W 0.50mm
- CC 0.5W 0.50mm
- CD 0.5W 0.50mm
- CE 0.5W 0.50mm
- CF 0.5W 0.50mm
- CG 0.5W 0.50mm
- CH 0.5W 0.50mm
- CI 0.5W 0.50mm
- CJ 0.5W 0.50mm
- CK 0.5W 0.50mm
- CL 0.5W 0.50mm
- CM 0.5W 0.50mm
- CN 0.5W 0.50mm
- CO 0.5W 0.50mm
- CP 0.5W 0.50mm
- CQ 0.5W 0.50mm
- CR 0.5W 0.50mm
- CS 0.5W 0.50mm
- CT 0.5W 0.50mm
- CU 0.5W 0.50mm
- CV 0.5W 0.50mm
- CW 0.5W 0.50mm
- CX 0.5W 0.50mm
- CY 0.5W 0.50mm
- CZ 0.5W 0.50mm
- DA 0.5W 0.50mm
- DB 0.5W 0.50mm
- DC 0.5W 0.50mm
- DD 0.5W 0.50mm
- DE 0.5W 0.50mm
- DF 0.5W 0.50mm
- DG 0.5W 0.50mm
- DH 0.5W 0.50mm
- DI 0.5W 0.50mm
- DJ 0.5W 0.50mm
- DK 0.5W 0.50mm
- DL 0.5W 0.50mm
- DM 0.5W 0.50mm
- DN 0.5W 0.50mm
- DO 0.5W 0.50mm
- DP 0.5W 0.50mm
- DQ 0.5W 0.50mm
- DR 0.5W 0.50mm
- DS 0.5W 0.50mm
- DT 0.5W 0.50mm
- DU 0.5W 0.50mm
- DV 0.5W 0.50mm
- DW 0.5W 0.50mm
- DX 0.5W 0.50mm
- DY 0.5W 0.50mm
- DZ 0.5W 0.50mm
- EA 0.5W 0.50mm
- EB 0.5W 0.50mm
- EC 0.5W 0.50mm
- ED 0.5W 0.50mm
- EE 0.5W 0.50mm
- EF 0.5W 0.50mm
- EG 0.5W 0.50mm
- EH 0.5W 0.50mm
- EI 0.5W 0.50mm
- EJ 0.5W 0.50mm
- EK 0.5W 0.50mm
- EL 0.5W 0.50mm
- EM 0.5W 0.50mm
- EN 0.5W 0.50mm
- EO 0.5W 0.50mm
- EP 0.5W 0.50mm
- EQ 0.5W 0.50mm
- ER 0.5W 0.50mm
- ES 0.5W 0.50mm
- ET 0.5W 0.50mm
- EU 0.5W 0.50mm
- EV 0.5W 0.50mm
- EW 0.5W 0.50mm
- EX 0.5W 0.50mm
- EY 0.5W 0.50mm
- EZ 0.5W 0.50mm
- FA 0.5W 0.50mm
- FB 0.5W 0.50mm
- FC 0.5W 0.50mm
- FD 0.5W 0.50mm
- FE 0.5W 0.50mm
- FF 0.5W 0.50mm
- FG 0.5W 0.50mm
- FH 0.5W 0.50mm
- FI 0.5W 0.50mm
- FJ 0.5W 0.50mm
- FK 0.5W 0.50mm
- FL 0.5W 0.50mm
- FM 0.5W 0.50mm
- FN 0.5W 0.50mm
- FO 0.5W 0.50mm
- FP 0.5W 0.50mm
- FQ 0.5W 0.50mm
- FR 0.5W 0.50mm
- FS 0.5W 0.50mm
- FT 0.5W 0.50mm
- FU 0.5W 0.50mm
- FV 0.5W 0.50mm
- FW 0.5W 0.50mm
- FX 0.5W 0.50mm
- FY 0.5W 0.50mm
- FZ 0.5W 0.50mm
- GA 0.5W 0.50mm
- GB 0.5W 0.50mm
- GC 0.5W 0.50mm
- GD 0.5W 0.50mm
- GE 0.5W 0.50mm
- GF 0.5W 0.50mm
- GG 0.5W 0.50mm
- GH 0.5W 0.50mm
- GI 0.5W 0.50mm
- GJ 0.5W 0.50mm
- GK 0.5W 0.50mm
- GL 0.5W 0.50mm
- GM 0.5W 0.50mm
- GN 0.5W 0.50mm
- GO 0.5W 0.50mm
- GP 0.5W 0.50mm
- GQ 0.5W 0.50mm
- GR 0.5W 0.50mm
- GS 0.5W 0.50mm
- GT 0.5W 0.50mm
- GU 0.5W 0.50mm
- GV 0.5W 0.50mm
- GW 0.5W 0.50mm
- GX 0.5W 0.50mm
- GY 0.5W 0.50mm
- GA 0.5W 0.50mm
- GB 0.5W 0.50mm
- GC 0.5W 0.50mm
- GD 0.5W 0.50mm
- GE 0.5W 0.50mm
- GF 0.5W 0.50mm
- GG 0.5W 0.50mm
- GH 0.5W 0.50mm
- GI 0.5W 0.50mm
- GJ 0.5W 0.50mm
- GK 0.5W 0.50mm
- GL 0.5W 0.50mm
- GM 0.5W 0.50mm
- GN 0.5W 0.50mm
- GO 0.5W 0.50mm
- GP 0.5W 0.50mm
- GQ 0.5W 0.50mm
- GR 0.5W 0.50mm
- GS 0.5W 0.50mm
- GT 0.5W 0.50mm
- GU 0.5W 0.50mm
- GV 0.5W 0.50mm
- GW 0.5W 0.50mm
- GX 0.5W 0.50mm
- GY 0.5W 0.50mm
- GA 0.5W 0.50mm
- GB 0.5W 0.50mm
- GC 0.5W 0.50mm
- GD 0.5W 0.50mm
- GE 0.5W 0.50mm
- GF 0.5W 0.50mm
- GG 0.5W 0.50mm
- GH 0.5W 0.50mm
- GI 0.5W 0.50mm
- GJ 0.5W 0.50mm
- GK 0.5W 0.50mm
- GL 0.5W 0.50mm
- GM 0.5W 0.50mm
- GN 0.5W 0.50mm
- GO 0.5W 0.50mm
- GP 0.5W 0.50mm
- GQ 0.5W 0.50mm
- GR 0.5W 0.50mm
- GS 0.5W 0.50mm
- GT 0.5W 0.50mm
- GU 0.5W 0.50mm
- GV 0.5W 0.50mm
- GW 0.5W 0.50mm
- GX 0.5W 0.50mm
- GY 0.5W 0.50mm

ALLISON HYBRID

RESOURCES: Wiring Schematics

APPENDIX H—EP 40/50 SYSTEM™ WIRING SCHEMATIC



WIRE NO.	RECOMMENDED COLOR	CLASS.	DESCRIPTION
100-PW11-1	YELLOW	D	+12V BATTERY RETURN
100-PW11-2	YELLOW	D	IGNITION
100-PW11-3	RED	E	+12V BATTERY
100-PW11-4	GREEN	F	+12V BATTERY RETURN
100-PW11-5	GREEN	E	ENGINE START REQUEST 1
100-PW11-6	WHITE	B	ENGINE START REQUEST 2
100-PW11-7	ORANGE	A	ACCELERATOR PEDAL INS 1
100-PW11-8	RED	C	ACCELERATOR PEDAL INS 2
100-PW11-9	BLUE	C	AUTOMATIC RETURN
100-PW11-10	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-11	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-12	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-13	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-14	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-15	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-16	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-17	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-18	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-19	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-20	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-21	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-22	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-23	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-24	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-25	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-26	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-27	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-28	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-29	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-30	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-31	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-32	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-33	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-34	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-35	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-36	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-37	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-38	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-39	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-40	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-41	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-42	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-43	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-44	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-45	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-46	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-47	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-48	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-49	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-50	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-51	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-52	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-53	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-54	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-55	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-56	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-57	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-58	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-59	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-60	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-61	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-62	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-63	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-64	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-65	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-66	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-67	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-68	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-69	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-70	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-71	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-72	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-73	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-74	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-75	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-76	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-77	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-78	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-79	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-80	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-81	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-82	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-83	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-84	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-85	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-86	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-87	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-88	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-89	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-90	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-91	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-92	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-93	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-94	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-95	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-96	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-97	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-98	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-99	BLUE	B	SHIFT SELECTOR WAKEUP
100-PW11-100	BLUE	B	SHIFT SELECTOR WAKEUP

1100710100

ALLISON HYBRID

RESOURCES: Wiring Schematics

APPENDIX H—EP 40/50 SYSTEM™ WIRING SCHEMATIC




Figure H-4. Allison Electric Drive™ Wiring Schematic—ESS

WIRE NO.	WIRE NO.	CLASS	DESCRIPTION
224	224-PT140-C	A	CAN HI
225	225-PT140-B	A	CAN SHIELD
226	226-PT140-A	A	ENERGY STORAGE RELAY CLOSED
227	227-PT140-H	E	+12V BATTERY
228	228-PT140-P	E	+12V BATTERY RETURN
229	229-PT140-R	E	+12V BATTERY WAKEUP
146	146-PT13-14	B	HVIL IN
152	152-PT13-23	B	HVIL OUT
12123022		B	+24V BATTERY RETURN
12123988		B	+24V BATTERY RETURN

* WIRE NUMBERS SHOWN IN SCHEMATIC MAY CONTAIN LETTER DESIGNATION WHERE SPLICED CIRCUITS EXIST

** WIRE CLASSES ARE DEFINED AS FOLLOWS:

- A 0.5V
- B 0.50mA
- C 0.50mA
- D 0.5VAT 0.2A
- E 0.5VAT 0.10A
- F 0.20VAC 0.50mA

INSERT CAVITY PLUGS IN ALL UNUSED CAVITIES OF SPECIFIED CONNECTORS. QUANTITY WILL VARY ACCORDING TO INSTALLATION INTERFACE REQUIREMENTS. THE PLUGS IS TO BE INSERTED UNTIL THE LARGER DIAMETER IS FLUSH WITH THE CONNECTOR BROWLINE.

WHEN FEATURES ARE NOT USED, ALL LEAD WIRES TO THOSE FEATURES ARE TO BE OMITTED.

CONNECTOR PART NUMBERS SHOWN ARE MATING CONNECTORS FOR ALLISON SUPPLIED HARDWARE ONLY

MATING CONNECTORS ARE CUSTOMER SUPPLIED


REFER TO ALLISON TECHNICAL DOCUMENT NO. 189 FOR INFORMATION ON WIRING HARNESSSES

FUSING INFORMATION	DPM
PT120-1, 2, 5, AND 6 18GA FUSED AT 10A TOGETHER (ONLY 1 FUSED TO +12V BATTERY)	
PT11-3 18GA FUSED AT 10A TO +12V BATTERY	YOM
PT13-3 18GA FUSED AT 10A TO +12V BATTERY	TCM
PT30-B 18GA FUSED AT 10A TO +12V BATTERY	DIAGNOSTIC (CAN)
PM10-A 18GA FUSED AT 10A TO +12V BATTERY	DRIVE UNIT
PM10-Q 18GA FUSED AT 10A TO +12V BATTERY	PRESS
PO16-R 18GA FUSED AT 10A TO +12V BATTERY	RELAY
K1-30 18GA FUSED AT 10A TO +12V BATTERY	RELAY
K2-30 18GA FUSED AT 10A TO +12V BATTERY	RELAY
K3-30 18GA FUSED AT 10A TO +12V BATTERY	RELAY
K4-30 18GA FUSED AT 10A TO +12V BATTERY	RELAY
PH40-F 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-P 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-S 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-U 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-V 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-W 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-X 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-Y 16GA FUSED AT 15A TO +12V BATTERY	ESS
PH40-Z 16GA FUSED AT 15A TO +12V BATTERY	ESS
231-PT140-A	
232-PT140-B	
233-PT140-C	
234-PT140-E	
235-PT140-I	

ALLISON HYBRID

RESOURCES: Wiring Schematics

APPENDIX H—E^P 40/50 SYSTEM™ WIRING SCHEMATIC



ALLISON HYBRID

DIAGNOSTICS – USING THE TROUBLESHOOTING MANUAL




Instructor Led Training

Using The Troubleshooting Manual

Troubleshooting Manual Appendices (cont'd)

- **Resistance vs. Temperature:**
 - Information related to solenoid resistance values as related to fluid temperatures.
- **Electronic Interference:**
 - Describes potential causes of, system reactions to and recommended repair procedures for externally-generated electronic interference.
- **Input/Output Functions:**
 - Includes wiring schematics and operational overview for available Input and Output features.
- **Fluid Check Procedures:**
 - Using the Oil Level Sensor to obtain sump fluid level.



View PDF View PDF View PDF View PDF

6 of 7



ALLISON HYBRID

RESOURCES: Resistance vs. Temperature

NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX J—RESISTANCE VS. TEMPERATURE

J-1. RESISTANCE VS. TEMPERATURE




Figure J-1. Temperature vs. Sensor Chart




Figure J-2. Solenoid Resistance vs. Temperature Graph



RESOURCES: Electronic Interference

NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX K—ELECTRONIC INTERFERENCE

K-1. ELECTROMAGNETIC INTERFERENCE (EMI)/RADIO FREQUENCY INTERFERENCE (RFI)

All electrical and electronic systems generate electromagnetic fields that can interfere with other electronic systems. Allison Transmission electronic transmission controls comply with Federal Communications Commission (FCC) regulations and other guidelines concerning emitted radio frequency interference for transportation electronics. The position of Allison Transmission Division of General Motors is that manufacturers and installers of Electromagnetic Interference (EMI)/Radio Frequency Interference (RFI) emitting equipment are responsible for adhering to FCC regulations and other guidelines concerning emitted radio frequency interference for transportation electronics.

Some radio-telephone or two-way communication radios (land-mobile radio), or the manner in which they are installed, can adversely affect vehicle operation or be affected by other vehicle components. Expenses incurred to protect vehicle-related systems from EMI/RFI emissions by radio-telephone or two-way communications radios (land-mobile radio) or to integrate such devices into vehicles are not the responsibility of Allison Transmission.

K-2. GENERAL GUIDELINES FOR RADIO EQUIPMENT INSTALLATION

The following general guidelines for installing radio-telephone or two-way communications radios (land-mobile radio) in a vehicle supplement, but DO NOT replace, detailed instructions provided by the radio equipment manufacturer. Detailed installation instructions are the sole responsibility of the radio equipment manufacturer.

Experience has shown that most EMI/RFI problems can be prevented or eliminated by following the guidelines. If EMI/RFI problems persist after following the guidelines and after ensuring the installation conforms to the guidelines, contact the vehicle and radio equipment manufacturers for additional installation or equipment operation instructions.

A. Transmitter Installation

1. Locate remote radio transmitters as far away from other electronic devices and as near to the side of the vehicle body as possible.
2. Mount transceivers (transmitter and receiver in one box) under the dash so as not to interfere with vehicle controls or passenger movement.

B. Antenna Installation

Each vehicle and body style reacts differently to radio frequency energy. When dealing with an unfamiliar vehicle, test various antenna locations by using a magnetic mount antenna and checking for adverse effects. Antenna location is a major factor in EMI/RFI problems.

C. Antenna Cable Routing

1. Use high quality, 95 percent shield coverage, coaxial (coax) cable. Route the coax well away from any electronic components.
2. Route antenna cables as far away from vehicle wiring as possible to reduce the likelihood of the vehicle wiring acting as an antenna for interference.

D. Radio Wiring and Connector Location

1. Connect transmitter power leads directly to the battery.
2. For transceivers (transmitter and receiver in one box) with ignition control, place a 12V power contactor at the vehicle battery. Drive the contactor coil, through an appropriate in-line fuse, from an ignition circuit not powered during engine cranking.
3. Any negative lead from a handset or control unit must return to battery negative.
4. Connect the positive lead from a handset or control unit directly to battery.
5. Fuse handset or control unit positive and negative leads separately from the transceiver negative and positive leads. Use correctly rated fuses.



RESOURCES: Input/Output Functions




NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX L—INPUT/OUTPUT FUNCTIONS

L-1. AUX FUNCTION RANGE INHIBIT



WARNING!

If this function is enabled in the calibration, the function **MUST** be integrated into the vehicle wiring. If the function is available in the calibration but will not be used in the vehicle, it **MUST** be disabled in the calibration.

DESCRIPTION: When this function is used and an auxiliary vehicle function is active, a neutral-to-range shift is inhibited. It will continue to be inhibited until the input signal from the auxiliary vehicle function is turned off.

NOTE: This function is active when the input is off (switch open) and is deactivated when the input is turned on (switch closed).

USES: This function prevents inadvertent range selection when auxiliary equipment, e.g., wheelchair lift, is operating. It may also be used to prevent neutral-to-range shifts unless the brake pedal is depressed.

VARIABLES TO SPECIFY: None

VOCATIONS: Various, not for emergency equipment. Typical uses: transit bus (wheelchair lift), utility truck (outriggers out), and motorhome (door ajar).



RESOURCES: Fluid Check Procedure



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX M—FLUID CHECK PROCEDURE

WARNING!

For vehicles containing the E^V Drive™, each time you park the vehicle or leave the operator's station with the engine running, do the following.

- Bring the vehicle to a complete stop using the service brake.
- Put the transmission in N (Neutral).
- Apply the emergency brake and/or parking brake, if present, and make sure it is properly engaged.
- If the operator's station will be unoccupied with the engine running, chock the wheels and take any other steps necessary to keep the vehicle from moving.

If this procedure is not followed, the vehicle can move suddenly and you or others could be injured.

The E^V Drive™ unit is equipped with an electronic Oil Level Sensor (OLS). The OLS provides a means to check the drive unit fluid level. To display fluid level, simultaneously press the Up (↑) and Down (↓) arrow keys on the pushbutton shift selector for five seconds.

As soon as fluid level information is requested, the TCM checks to see if conditions are right to allow a fluid level check. Certain operating conditions must have been met for a period of two minutes before fluid level is checked. These operating conditions are:

- Engine at idle (625–850 rpm)
- Sump fluid at operating temperature of 20–80°C (68–176°F)
- E^V Drive™ output shaft stopped
- E^V Drive™ in N (Neutral)
- Oil level sensor functioning properly

If the two-minute period has elapsed before the fluid level check request, information is displayed immediately. However, if the two-minute period has not elapsed, a countdown displays before fluid level information displays. The countdown display flashes constantly. The countdown starts at 8 and decreases sequentially to 1 during the two-minute period.

When a fluid level check is requested, and the two-minute countdown is in process, the flashing display shows the number corresponding to the countdown progress. For example—if the fluid level check were requested in the middle of the two-minute countdown period, the display would flash a 5 or a 4 and decrease to 1.



ALLISON HYBRID

DIAGNOSTICS – USING THE TROUBLESHOOTING MANUAL



Instructor
Led
Training

Using The Troubleshooting Manual

Troubleshooting Manual Appendices (cont'd)

- **Support Equipment:**
 - *Listing of available auxiliary components and their operation.*
- **Controller Area Network (CAN):**
 - *Includes operational overview and basic diagnostic procedures for J1939 backbones.*
- **DPIM Installation Protection Device (DIPD):**
 - *Description and use of the DIPD.*
- **Battery Pack Installation Protection Device (BIPD):**
 - *Description and use of the BIPD.*

E⁺ 40/50 SYSTEM™ TROUBLESHOOTING MANUAL APPENDIX R—DPIM INSTALLATION PROTECTION DEVICE (DIPD)

R-1. INTRODUCTION

Before connecting a Dual Power Inverter Module (DPIM), system control wiring must be tested to prevent damaging voltages from being applied to various low voltage system interconnection points.

The DPIM Installation Protection Device (DIPD) tests for the presence of any damaging voltages. The DIPD interfaces to the system by way of the DPIM low voltage connectors and wiring harnessing.

The DIPD is used after the system is completed but before the DPIM is connected to the system control wiring. The DIPD is connected to the low voltage control system wiring in place of the DPIM. The system's low voltage supply is energized.

The DIPD contains no

The DIPD is

pin assoc-

lower than

Table A1 p

The DIPD p

low voltage

installed f




Figure P-1. J1939-11 Twisted Shielded Pair Cable

View PDF View PDF View PDF View PDF

7 of 7



RESOURCES: Support Equipment



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

E^P 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX N—SUPPORT EQUIPMENT

N-1. GENERAL

Various types of auxiliary components and/or equipment may be required to complete the installation of an E^P 40/50 Parallel Hybrid Electric Drive Propulsion System and its options. These items are commonly referred to as “support equipment”. Some of the required items are available from Allison as an integral part of the propulsion system, e.g., an output yoke or flange. Other items, such as a Pushbutton Shift Selector (PBSS), are available from Allison, but must be specifically ordered. The remaining support equipment items are available from outside sources. Allison parts may be obtained through your order correspondent at the Allison Parts Distribution Center (PDC). If you do not have an order correspondent, contact PDC per the following:

Allison Transmission
Parts Distribution Center (PDC)
5902 Decatur Boulevard
Indianapolis, IN 46241-9579
Phone: (317) 821-5104

The addresses of suppliers listed in this section are included at the end of the document. This list may not include all sources of support equipment, nor does it constitute approval or recommendation of a particular item or supplier. The reliability and warranty coverage of these components are the responsibility of the supplier.

N-2. LOW VOLTAGE WIRING HARNESS AND CONNECTOR COVERS

The propulsion system controls require the use of wiring harnesses to connect the various system components. Wiring harnesses are available from:

- St. Clair Technologies Inc.

Unused connectors must be sealed with a mating connector and cavity pins, or an appropriate connector cover. Connector covers are available from:

- St. Clair Technologies, Inc.

N-3. HIGH VOLTAGE

A. Wiring

All high voltage wiring (Drive Unit to DPIM and DPIM to ESS) is to be 1/0 cable. Wiring is to be shielded and covered with orange conduit. If orange conduit cannot be used, the cables should be bundled and marked with orange to signify high voltage.

1. Drive Unit to DPIM

To assure compatibility with the seals used at the connections at both the Drive Unit and DPIM ends of these cables, the O.D. must be 15 mm (0.59 inch). See *Section B, Controls Component Installation*, for further details.

1/0 cable that meets all the requirements is made by D&B Industrial Group (Rowe Industries) and is designated: CSA AWM I A/B 150C 600V FT1 M16878/30 1000V 1/0 AWG. This cable, shielding, and conduit is available from:

- PEI Genesis, Incorporated
- Meunier Electronic Supply
- Astro Industries, Incorporated



RESOURCES: Control Area Network (CAN)

NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX P—CONTROL AREA NETWORK (CAN)

P-1. PHYSICAL LAYER—BASIC DESCRIPTION

The CAN (Control Area Network) physical layer is a two-wire connection using a twisted shielded pair. The two wires are defined as CAN High (typically yellow) and CAN Low (typically green). A termination resistor is applied at both ends of the CAN backbone, between CAN High and CAN Low. Typical bus termination resistors are 120 Ohms, 5 percent, 1/4 watt.

Terminology:

- CAN—Control Area Network
- CAN BACKBONE—The main avenue of communication wiring between the two termination resistor connections
- STUB—The CAN wiring between the CAN BACKBONE and NODE
- NODE—An electronic controller attached to the end of a stub




Figure P-1. J1939-11 Twisted Shielded Pair Cable

P-2. COMMON PROBLEMS

OPEN CIRCUITS—A (CAN High) or B (CAN Low) or both, in backbone or in a stub can affect one or multiple controllers on the network.

SHORT CIRCUITS—A (CAN High) or B (CAN Low) to battery, ground, shield or each other. ANY short, ANY location will result in an in-operable datalink (gauges dead, tools will not communicate, DTCs, etc.).

- Incorrectly wired pins on one or more of the controllers.
- Connector seal(s) missing; water intrusion or corrosion

SHIELDING—Effective shielding requires 100 percent coverage of the communication wires, a small opening can render the shielding worthless and susceptible to noise.



RESOURCES:

DPIM Installation Protection Device (DIPD)



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

EP 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX R—DPIM INSTALLATION PROTECTION DEVICE (DIPD)

R-1. INTRODUCTION

Before connecting a Dual Power Inverter Module (DPIM), system control wiring must be tested to prevent damaging voltages from being applied to various low voltage system interconnection points.

The DPIM Installation Protection Device (DIPD) tests for the presence of any damaging voltages. The DIPD interfaces to the system by way of the DPIM low voltage connectors and wiring harnessing.

The DIPD is used after the system is completed but before the DPIM is connected to the system control wiring. The DIPD is connected to the low voltage control system wiring in place of the DPIM. The system's low voltage supply is energized, and the vehicle ignition switch is turned on. DIPD testing confirms that the low voltage wiring harness contains no miswiring, shorts, or grounds that could damage the DPIM.

The DIPD detects the presence of voltage levels, above the maximum allowed on any single pin, or combination of pins associated with the DPIM low voltage system interconnections. In some instances, a voltage significantly lower than the maximum allowable will be considered a failure if that voltage level is indicative of improper wiring. Table A1 provides a listing of the (nominal/maximum) voltage failure set point for each interconnection point.

The DIPD provides a visual indication verifying that no potentially damaging voltages could be applied to the DPIM low voltage system interconnection points. **The DIPD does not prove that a wiring installation is correctly installed for proper ESS operation.**

R-2. FUNCTIONAL DESCRIPTION

The DIPD simulates the 12V sensor supply voltages normally supplied by the DPIM internal circuitry and makes appropriate measurements to ensure this power has not been inadvertently routed to another interconnection point on the DPIM which could be damaged by the application of 12VDC.

The DIPD provides a visual indication of the following:

- Proper low voltage supply and ground connections to the system
- Supply power within proper voltage range
- Proper system initial conditions met
- No improper voltage applied to any applicable pin(s)

NOTE: *A failed test turns off or blinks the associated indicator lamp.*

When connected and then energized, the DIPD performs a one second illumination test of all indicator lamps.

R-3. OPERATING INSTRUCTIONS

The DIPD connects to the control system by way of three low voltage connectors that are mated to the system harnessing in the same manner as a DPIM. These connectors are designated as J1 (Red, 32-pin), J2 (Gray, 32-pin) and J3 (Black, 24-pin)

All wiring installation and any other construction efforts which could damage system wiring, must be completed throughout the entire vehicle before conducting DIPD testing.

Use the DIPD to test the vehicle low voltage harness installation after any maintenance or modification that affects Energy Storage System low voltage interface wiring.

A. DIPD Test Procedure

DIPD testing requires that a DPIM is not connected to the low voltage wiring harness. If a DPIM is connected, the DPIM must be fully de-energized and the low voltage wiring harness connectors (J1, J2, and J3) disconnected from the DPIM before testing.



RESOURCES:

Battery Pack Installation Protection Device (BIPD)



NOTE: This resource link has multiple pages and information changes frequently. Reference the source document for complete, current information.

E^P 40/50 SYSTEM™ TROUBLESHOOTING MANUAL

APPENDIX S—BATTERY PACK INSTALLATION PROTECTION DEVICE (BIPD)

S-1. INTRODUCTION

When installing an Energy Storage System (Battery Pack) potentially damaging voltages must be prevented from being applied to various low voltage system interconnection points.

The Battery Pack Installation Protection Device (BIPD) tests for the presence of any potentially damaging voltages. The BIPD interfaces to the system by way of the Energy Storage System (ESS) low voltage connectors and wiring harnessing.

The BIPD is used after the system is completed but before the ESS is connected to the system wiring. The BIPD is connected to the low voltage control system wiring in place of the ESS. The system's low voltage supply is energized, and the vehicle ignition switch is turned on. BIPD testing confirms that the low voltage wiring harness contains no miswiring, shorts, or grounds that could damage the ESS.

The BIPD provides a visual indication verifying that no potentially damaging voltages could be applied to the ESS low voltage system interconnection points. **The BIPD does not prove that a wiring installation is correctly installed for proper ESS operation.**

S-2. FUNCTIONAL DESCRIPTION

The BIPD detects the presence of voltage levels above or below those allowed on any single pin, or combination of pins associated with the Battery Pack low voltage system interconnections. Table S-1 provides a listing of the maximum, minimum, and failure voltages for each interconnection point.

The BIPD provides a visual indication of the following:

1. Proper low voltage supply and ground connections to the system
2. Supply power within proper voltage range
3. Proper system initial conditions met
4. No improper voltage applied to any applicable pin(s)

NOTE: *A failed test turns off the associated indicator lamp.*

When connected and then energized, the BIPD performs a one second illumination test of all indicator lamps.

S-3. OPERATING INSTRUCTIONS

The BIPD connects to the system wiring harness in the same manner as the ESS. To ensure a meaningful test all wiring installation and any other vehicle construction that could potentially damage system wiring must be completed before testing with the BIPD.

Use the BIPD to test the vehicle low voltage harness installation after any maintenance or modification that affects Energy Storage System low voltage interface wiring.

A. BIPD Test Procedure

A BIPD test cannot be conducted with the battery Pack connected to the low voltage wiring harness. Disconnect the low voltage wiring harness from the battery pack before conducting a BIPD test.

B. Establish Proper Initial Test Conditions:

Various BIPD display combinations may exist as proper initial system conditions for testing. These displays are evaluated in subsequent operations and may be ignored until initial test conditions are established.

1. Be sure all 12VDC and/or 24VDC power-interrupting devices, power cut-off switches, circuit breakers, etc. are configured for normal system operation of the test system.

